



M1 Lite Push Trolley  
Instruction Manual

---

**REGISTER ONLINE**  
[www.motocaddy.com/warranty](http://www.motocaddy.com/warranty)

# Locating your Serial Number / Caring for your Trolley

## Locating your Serial Number

The serial number for the M1 Lite Push Cart is located on the underside of the trolley frame underneath the rear cool bag strap. This number is required when registering your warranty online and should be kept handy for future use.

The same number should also be on the box received with your trolley. Please ensure you keep hold of the packaging in case you need to return your trolley for any reason. A proof of purchase must also be kept in case your trolley requires servicing during its warranty period.

**Please keep a record of your trolley serial number here for future reference**

M	C	M												
---	---	---	--	--	--	--	--	--	--	--	--	--	--	--

## Caring for your Trolley

The M1 Lite Push Cart is designed to require very little maintenance; however we recommend regular checks to ensure:

- There is no build up of excess mud and dirt
- The rear wheel axles are kept clean to maintain smooth operation
- Excess water is wiped from the trolley prior to storage

## Unfolding your Trolley

1. Push carry handle back (fig. 1)
2. Press release button #1 and push front wheel away from trolley until it is fully extended and trolley is flat
3. Push handle down to lock wheel in place (fig. 2)
4. Pull CLIP 2 outwards to release (fig. 3)
5. Unfold handle towards front wheel and re-secure CLIP 2 to lock
6. Press release button #3 to fully extend rear wheels (each wheel is operated by separate sides of the button) (fig. 4)
7. Unfold wishbone into upright position
8. Hook the lower part of the frame into the clip (fig. 5)
9. Simply unfold the upper part of the frame until CLIP 4 locks the upper frame in place
10. Adjust upper bag supports ready for use



Fig 1




Fig 2



Fig 3




Fig 4



Fig 5

# Folding your Trolley

## Folding your Trolley

1. Fold back upper bag supports
2. Pull CLIP 4 up to release locking system (fig. 1)
3. Fold the frame in half and push handle towards front wheel
4. Fold wishbone towards front wheel
5. Push rear wheels in towards the trolley (fig. 2)
6. Pull CLIP 2 outwards to release (fig. 3)
7. Fold handle towards rear wheels and re-secure CLIP 2 to lock
8. Use the carry handle to lift trolley until the front wheel folds and locks in to place. (fig. 4)




Fig 1




Fig 2



Fig 3



Fig 4

## Using the Lower Bag Supports

This Motocaddy trolley is fitted with the new EASILOCK™ bag attachment system.

If you are using an EASILOCK™ compatible cart bag please follow these simple instructions:

1. Remove the two pre-fitted lower bag straps by depressing the rear button and sliding (fig 1)
2. Match up the indicating line on your cart bag with the line on the lower bag support
3. Lower bag until the pins lock in position

If you are using a non-EASILOCK™ bag, please use the following instructions:

1. Stretch the elasticated strap around the bag
2. Loop the rounded bar underneath the hook (fig. 2)
3. Position the two placement straps centrally on your cart bag (fig. 3)

Please ensure the straps are hooked in place securely before releasing.  
Failure to do so could result in injury to the user.



Fig 1



Fig 2



Fig 3

# Using the Upper Bag Supports / Adjusting the Bag Supports

## Using the Upper Bag Supports

The upper bag support straps can be secured using the same steps as the non-EASILOCK instructions overleaf:

1. Stretch the elasticated strap around the bag
2. Loop the rounded bar underneath the hook (fig. 2 overleaf)
3. Position the two placement straps centrally on your cart bag (fig. 3 overleaf)

## Adjusting the Bag Supports

The bag support straps are manufactured from elasticated material to allow your golf bag to be held tightly in place.

The strap should be adjusted to be reasonably tight around the golf bag:

1. Unclip the elasticated straps from the housing by pulling outwards in the direction shown by the arrows (fig. 1)
2. Move the bar as required to tighten or loosen the strap fitting. Pulling the bar downwards will tighten, pushing it upwards will loosen (fig. 2)
3. Ensure that the straps are clipped back in to the housing before use (fig. 3)



Fig 1



Fig 2



Fig 3

## Using the Parking Brake

The brake on your Motocaddy M1 Lite trolley is designed to be used as a parking brake (like a hand brake of a car or foot brake on a pram).

When applying the brake you should make sure that the trolley has completely stopped moving first.

**WARNING:** Attempting to apply the brake whilst the trolley is still in motion may cause damage to the trolley and could invalidate the warranty.

Always ensure that the parking brake has been disengaged before attempting to set off again.







Motocaddy Ltd, Units 15 - 18 Stansted Distribution Centre,  
Start Hill, Great Hallingbury, Hertfordshire, CM22 7DG

t: +44 (0)1279 712 370 e: [info@motocaddy.com](mailto:info@motocaddy.com) w: [www.motocaddy.com](http://www.motocaddy.com)



We are dedicated to protecting the environment and encourage the recycling of Motocaddy products through a free collection and disposal service. To find out more or to locate your nearest Motocaddy recycling point, please contact us through our website.

MC.14.21.002